# 8 Frequency Converter Wiring

## 8.1 Wiring Diagram




**Fig. 8-1:** Wiring diagram

- For cable size, fuse, screw torque, see chapter 8.2 "Cable Specifications" on page 38.
- For terminals, see chapter 8.3 "Terminals" on page 42.
- ①: NPN modes, see fig. 8-9 "Digital input NPN / PNP wiring" on page 51.
- *: Can be disconnected by disassembly of a screw.
- Pulse input can be **ONLY** set via 'Multi-function digital input X5'.